



# Driver Installation

80mm Thermal Receipt Printer



Scan the QR code or log in to the official website to download the driver.






آموزش نصب درایور پرینتر

## POS Printer Driver Setup

V7.17

جهت نصب صحیح درایور پرینتر  
ATOM مراحل شماره گذاری و  
توضیحات ارایه شده است.



Setup

Ready to Install

Setup is now ready to begin installing POS Printer Driver V7.17 on your computer.

Click Install to continue with the installation, or click Back if you want to review or change any settings.

Destination location:  
C:\POS Printer Driver V7.17

Additional tasks:  
Additional shortcuts:  
Create a desktop shortcut

ادامہ نصب

5

Back

Install

Cancel

Setup

Completing the POS Printer Driver V7.17 Setup Wizard

Setup has finished installing POS Printer Driver V7.17 on your computer. The application may be launched by selecting the installed shortcuts.

Click Finish to exit Setup.

☒ Launch POS Printer Driver V7.17

ادامہ نصب

6

Finish

انتخاب درگاہ ارتباط

انتخاب POS-80C

شناسایی درگاہ USB

انتخاب نسخه ویندوز

انتخاب سری پرینتر

ادامہ نصب

11

12

10

7

8

9

1

Install Configuration

You are using Windows 10 x64 OS. Please select Windows 10 to install.

Select Windows OS

☐ Windows XP

☐ Windows Vista

☐ Windows 2003

☐ Windows 8/8.1

☐ Windows 7

☒ Windows 10

☐ Windows 11

7

Printer Interface : ☒ USB ☐ Other

8

Select Printer Series

☐ POS-58

☐ POS-58C

☐ POS-80C

☐ POS-90

☐ POS-76

☐ POS-76C

9

\*Remarks: "C" means item with cutter

☐ Set Default Printer

10

Check USB Port

11

12

Install Now

Cancel

Install Configuration

You are using Windows 10 x64 OS. Please select Windows 10 to install.

Select Windows OS

☐ Windows XP

☐ Windows Vista

☐ Windows 2003

☐ Windows 8/8.1

POS Printer Driver V7.17

پایان نصب درایور

Succeed !

Do you want to configure printer now?

Yes

No

☐ POS-76

☐ POS-76C

\*Remarks: "C" means item with cutter

☐ Set Default Printer

Check USB Port

Install Now

Cancel

